

VFR CIRCUIT PROCEDURES AT UNCONTROLLED AERODROMES

Communications Requirements

Information can be exchanged with a flight service station (FSS), community aerodrome radio station (CARS), universal communications (UNICOM), or vehicle operators by directed transmissions, or with other aircraft by broadcast transmissions. See the *Transport Canada Aeronautical Information Manual* (TC AIM) RAC 4.5 for the current requirements.

It is essential that pilots be aware of other traffic and exchange information when approaching or departing an uncontrolled aerodrome, since some aircraft may be receiver only (RONLY) or no radio (NORDO).

Standard Left-Hand Pattern

Before arriving at an uncontrolled aerodrome, plan your approach to the circuit.

If it is necessary to cross over the aerodrome prior to joining the circuit, or after departure, it is recommended that the crossover be made at least 500 ft above the circuit altitude.

Where designated, a mandatory frequency (MF) or aerodrome traffic frequency (ATF) area is normally a circle with a 5-NM radius, capped at 3 000 ft above aerodrome elevation (AAE). All radio-equipped aircraft must monitor a common designated frequency.


At aerodromes that have published instrument approaches, the MF area may be expanded to include the approach area. See the *Canada Flight Supplement* (CFS) for current information.

Transiting Aircraft

Overflying Aerodromes (See TC AIM RAC 5.5)

Transiting aircraft shall not operate at a height of less than 2 000 ft above an aerodrome.
[Canadian Aviation Regulation (CAR) 602.96(4)]

At aerodromes where MF procedures are in effect, aircraft may also join the circuit from the flight paths indicated in blue.



MF/ATF Communication Procedures (see TC AIM 4.5.7)

Note: If your aircraft is radio-equipped, it is recommended that the same calls be made at non-MF aerodromes.

Arrival: (CAR 602.101)

- Report position, altitude, arrival procedure intentions and estimated time of landing (ETL) at least 5 min prior to entering the area.
- Maintain a listening watch on the designated frequency.
- Report when joining the circuit, giving position in the pattern.
- Report when on the downwind leg, if applicable.
- Report when established on final.
- Report when clear of the active runway after landing.

Operations on manoeuvring area: (CAR 602.99)

- Report intentions and maintain listening watch prior to entering the manoeuvring area.

Departure: (CAR 602.100)


- Report intentions before moving onto take-off surface.
- Ascertain by radio and by visual observation that no conflict is likely during takeoff.
- Report departure from aerodrome traffic circuit.
- Monitor the designated frequency until well clear of the MF/ATF area.

Circuits: (CAR 602.102)

- Report when entering the downwind leg.
- Report, with intentions, when established on final.
- Report when clear of the active runway after the final landing.

DEPARTURES

Climb to circuit altitude before making any turns.



CAUTION

At non-MF aerodromes, or when MF procedures are not invoked, keep a sharp lookout. NORDO traffic may also be established in, or be entering, the circuit without other traffic or the ground station being aware.

If the aerodrome is equipped with an instrument approach, IFR arrivals may also be landing via straight-in or circling procedures.

See CAR 602 Division V, TC AIM (TP 14371) and the CFS for the latest information.